


ideal  
**WORK**<sup>®</sup>

innovative surfaces

Installation



# Ideal Joint Performance

Ideal WORK S.r.l. - Via Kennedy, 52 31030 Vallà di Riese Pio X (TV) Italia  
Tel. (+39) 0423 4535 - Fax (+39) 0423 748429 - [www.idealwork.it](http://www.idealwork.it) [info@idealwork.it](mailto:info@idealwork.it)

# 01




Positioning on the joint line.

# 02



Installation with PVC screws.

# 03



Alignment of Ideal Joint.

# 04



Set to level.

# 05



Instal the upper reinforcement in to the performance joint base.

# 06



Joint material application and installation of the plastic sleeves.

# 07



Placing of the steel mesh and dowel bars.

# 08




Reinforce with formwork stakes or pins to restringht during concrete placement.



Do not stand on the dowel bars during the placement of the concrete.

# 09



The next day use a grinder with an abrasive blade to cut the PVC screws through the center of the Ideal Joint performance. The abrasive blade is provided by Ideal Work.